

Two Tier **Bike Rack** BR.500_S

single, spacing 500 mm



Base Modules

Extension Modules

Dimensions

Models

Configuration example





Office & Production facility

95-020 Bedoń k/Łodzi
ul.Brzezińska 57



Contact

e-mail: offer@sawo.com.pl



Basic Modules - main dimensions



spacing 500



Extension Modules - main dimensions



spacing 500

BR.500_S_X_XX

Single Basic-1 Modules. *spacing 500*

DIMENSIONS: BR.500_S_B_XX

| TYPE | D | B1 | BAN | B max | Weight [kg] |
|---------------|------|-----|------|-------|-------------|
| - | - | - | - | - | - |
| BR.500_S_B_12 | 2045 | 500 | 3000 | 3180 | 289 |
| BR.500_S_B_08 | 2045 | 500 | 2000 | 2180 | 207 |
| BR.500_S_B_04 | 2045 | 500 | 1000 | 1180 | 125 |

Extension modules for single Basic-1 modules. *spacing 500*

DIMENSIONS: BR.500_S_E_XX

| TYPE | D | B1 | BAN | B-Ex | Weight [kg] |
|----------------|------|-----|------|------|-------------|
| - | - | - | - | - | - |
| - | - | - | - | - | - |
| BR.500_S_E_12 | 2045 | 500 | 3000 | 3000 | 267 |
| BR.500_S_E_10* | 2045 | 500 | 2500 | 2500 | 225 |
| BR.500_S_E_08 | 2045 | 500 | 2000 | 2000 | 186 |
| BR.500_S_E_06* | 2045 | 500 | 1500 | 1500 | 144 |
| BR.500_S_E_04 | 2045 | 500 | 1000 | 1000 | 104 |

* An extension can only be used as the last module in a row

Single Basic-2 Modules. *spacing 500*

DIMENSIONS: BR.500_S_B_XX


Non-extensible modules

| TYPE | D | B1 | BAN | B max | Weight [kg] |
|-----------------|------|-----|------|-------|-------------|
| - | - | - | - | - | - |
| BR.500_S_B_10** | 2045 | 500 | 2500 | 2680 | 247 |
| BR.500_S_B_06** | 2045 | 500 | 1500 | 1680 | 166 |

**Free-standing racks only - cannot be extended with additional modules

Single Basic-1 Modules

spacing 500





DIMENSIONS: BR.500_S_B_xx



| TYPE | D | B1 | BAN | B max | Weight [kg] |
|---------------|------|-----|------|-------|-------------|
| - | - | - | - | - | - |
| BR.500_S_B_12 | 2045 | 500 | 3000 | 3180 | 289 |
| BR.500_S_B_08 | 2045 | 500 | 2000 | 2180 | 207 |
| BR.500_S_B_04 | 2045 | 500 | 1000 | 1180 | 125 |

All dim. in [mm]



BR.500_S_B_12




BR.500_S_B_08



BR.500_S_B_04



Extension modules for single Basic-1 modules. *spacing 500*





DIMENSIONS: BR.500_S_E_xx

| TYPE | D | B1 | BAN | B-Ex | Weight [kg] |
|----------------|------|-----|------|------|-------------|
| - | - | - | - | - | - |
| - | - | - | - | - | - |
| BR.500_S_E_12 | 2045 | 500 | 3000 | 3000 | 267 |
| BR.500_S_E_10* | 2045 | 500 | 2500 | 2500 | 225 |



* An extension can only be used as the last module in a row

All dim. in [mm]


BR.500_S_E_12



BR.500_S_E_10



Extension modules for single Basic-1 modules. *spacing 500*





DIMENSIONS: BR.500_S_E_xx

| TYPE | D | B1 | BAN | B-Ex | Weight [kg] |
|----------------|------|-----|------|------|-------------|
| BR.500_S_E_08 | 2045 | 500 | 2000 | 2000 | 186 |
| BR.500_S_E_06* | 2045 | 500 | 1500 | 1500 | 144 |
| BR.500_S_E_04 | 2045 | 500 | 1000 | 1000 | 104 |



* An extension can only be used as the last module in a row

All dim. in [mm]



BR.500_S_E_08



BR.500_S_E_06




BR.500_S_E_04



Single Basic-2 Modules

spacing 500

Non-extensible modules




DIMENSIONS: BR.500_S_B_xx

| TYPE | D | B1 | BAN | B max | Weight [kg] |
|-----------------|------|-----|------|-------|-------------|
| - | - | - | - | - | - |
| BR.500_S_B_10** | 2045 | 500 | 2500 | 2680 | 247 |
| BR.500_S_B_06** | 2045 | 500 | 1500 | 1680 | 166 |

**Free-standing racks only - cannot be extended with additional modules

All dim. in [mm]

BR.500_S_B_10



BR.500_S_B_06

